

Lab #5


Current/Voltage Curves and Efficiency Measurements

R.J. Ellingson and M.J. Heben

October 22, 2013

PHYS 4580, 6280, and 7280


Simple solar cell structure



The Diode Equation

Ideal Diode Law

$$I = I_0 \left(e^{\frac{qV}{kT}} - 1 \right)$$



I = net current;

I_0 = "dark saturation current", aka diode leakage current, aka reverse saturation current;

V = applied voltage across the terminals of the diode;


q = electron charge;

k = Boltzmann's constant;

T = absolute temperature (K).

I_0 is a property of the junction interfaces and recombination in the device.

Light Generated Current is Opposite Direction of Forward Dark Current




Principle of Superposition

$$I = I_0 \left[\exp\left(\frac{qV}{nkT}\right) - 1 \right] - I_L$$



Where n is the diode quality factor, reflects type of recombination in the device

Homojunction solar cell (e.g., Silicon)


p-type emitter (window)
n-type base (absorber)





+J under forward bias



n-type emitter (window)
p-type base (absorber)



+J under forward bias



Typical Si device configuration

Light Generated Current is Opposite Direction of Forward Dark Current

IV Curve

- The IV curve of a solar cell is the superposition of the IV curve in the dark with a constant light-generated current (I_L).
- The light current shift the J/V curve down so V_{OC} occurs near the “turn-on knee” in the diode curve.

I_L = light generated current.


$$I = I_0 \left[\exp\left(\frac{qV}{nkT}\right) - 1 \right] - I_L$$

Go to Animation



Short circuit photocurrent

The short-circuit current (I_{SC}) is the current through the solar cell when the voltage across the solar cell is zero (i.e., when the solar cell is short circuited). Usually written as I_{SC} , the short-circuit current is shown on the IV curve below.



I_{SC} is due to the generation and collection of light-generated carriers. For an ideal PV cell with moderate resistive loss, I_{SC} and the light-generated current are identical (I_{SC} is the largest current which may be drawn from the solar cell).

Short circuit (photo)current (I_{SC}) or current density (J_{SC})

- I_{SC} (or J_{SC}) is the current (or current density) when the device leads are “shorted” (i.e., connected electrically to one another)

I_{SC} depends on a number of factors, as follows :

the area of the solar cell. To remove the dependence of the solar cell area, it is more common to list the short-circuit current **density** (J_{sc} in mA/cm²) rather than the short-circuit current;

the number of photons (i.e., the power of the incident light source). I_{sc} from a solar cell is directly dependant on the light intensity;


the spectrum of the incident light. For most solar cell measurement, the spectrum is standardised to the AM1.5 spectrum;

the optical properties (absorption and reflection) of the solar cell (discussed in Optical Losses); and

the collection probability of the solar cell, which depends chiefly on the surface passivation and the minority carrier lifetime in the absorber.

Open circuit photovoltage (V_{OC})

The open-circuit voltage, V_{OC} , is the maximum voltage available from a solar cell, and this occurs at zero current. The open-circuit voltage corresponds to the amount of forward bias on the solar cell due to the bias of the solar cell junction with the light-generated current. The open-circuit voltage is shown on the IV curve below.




An equation for V_{OC} is found by setting the total current equal to zero, giving:

$$V_{OC} = \frac{nkT}{q} \ln \left(\frac{I_L}{I_o} + 1 \right)$$

Solar cell fill factor (FF) and Max Power Point (mpp)

At both of the operating points corresponding to I_{sc} and V_{oc} , the power from the solar cell is zero. The "fill factor" (FF) is the parameter which, in conjunction with V_{oc} and I_{sc} , determines the maximum power from a solar cell. The FF is defined as the ratio of the maximum power from the solar cell to the product of V_{oc} and I_{sc} . Graphically, the FF is a measure of the "squareness" of the solar cell and is also the area of the largest rectangle which will fit in the IV curve. The FF is illustrated below:



$$P_{out} = I * V$$
$$\frac{dP}{dV} = 0$$

Graph of cell output current (red line) and power (blue line) as function of voltage. Also shown are the cell short-circuit current (I_{sc}) and open-circuit voltage (V_{oc}) points, as well as the maximum power point (V_{mp} , I_{mp}). Click on the graph to see how the curve changes for a cell with low FF.

Solar cell efficiency

The efficiency of a solar cell (sometimes known as the power conversion efficiency, or PCE, and also often abbreviated η) represents the ratio where the output electrical power at the maximum power point on the IV curve is divided by the incident light power – typically using a standard AM1.5G simulated solar spectrum.

The efficiency of a solar cell is determined as the fraction of incident power which is converted to electricity and is defined as:

$$P_{\max} = V_{OC} I_{SC} FF \qquad \eta = \frac{V_{OC} I_{SC} FF}{P_{inc}}$$

where V_{oc} is the open-circuit voltage;

where I_{sc} is the short-circuit current; and



where FF is the fill factor

where η is the efficiency.

Power in AM1.5G spectrum is 1kW/m^2 , or 100 mW/cm^2

For a $10 \times 10\text{ cm}^2$ cell, the input power (AM1.5G) is $100\text{ mW/cm}^2 \times 100\text{ cm}^2 = 10\text{ W}$.

Impact of Electrical Loss Due to High Series Resistance (R_S) PV cells



Diode equation with R_S and R_{SH} :

$$I = I_L - I_0 \exp \left[\frac{q(V + IR_S)}{nkT} \right] - \frac{V + IR_S}{R_{SH}}$$